# **SUMIDIA Binderless**



M39 to M41

SUMIDI Binderle

SUMIDIA

SUMIDIA Binderless

SUMIDIA Binderless Nano-Polycrystalline Diamond Tool / SUMIDIA Binderless ··· M40

MOLD FINISH MASTER / SUMIDIA Binderless Ball-nose Endmills NPDB Type · · · M41

# **SUMIDIA Binderless**



#### General Features


SUMIDIA Binderless is polycrystalline diamond that directly binds nano-order diamond particles with high strength without using any binders. SUMIDIA Binderless is harder than single-crystal diamond and has no cleavability. Therefore, it enables machining of hard, brittle material such as carbides and makes possible new machining methods.

#### Characteristic

- SUMIDIA Binderless is a pure diamond, but, unlike single-crystal diamonds, has no anisotropy. Therefore, it displays excellent wear resistance with less uneven wear
- Thanks to its polycrystalline structure, SUMIDIA Binderless has no cleavability peculiar to single-crystal diamonds and displays excellent fracture resistance.


# ■ Comparison of Structures

SUMIDIA Binderless SEM Image




Diamond Grains (30 to 50nm)

Conventional PCD SEM Image




Diamond Grains (1 to 10µm)

#### Hardness



# ■ Application Examples of SUMIDIA Binderless

●Ballnose Endmill (Direct Cutting of Carbide)





# ●Indexable Insert (Turning of Carbide)








NPDB Type Stock Page 188

#### ■ General Features


The NPDB type enables direct mirror finishing of carbide, which is impossible for existing single-crystal or polycrystalline diamonds, by employing nanopolycrystalline diamond, which is harder than single-crystal diamond, for the cutting edge.

#### Characteristic

- Ideal for Finishing of Hard, Brittle Materials Including Carbide
   Provides excellent machined surface quality thanks to the sharp cutting edge and optimized edge treatment.
- Enables High-Precision Machining and Achieves Long Tool Life
  Maintains excellent dimensional accuracy for a long time thanks to the high contour accuracy of the cutting edge and the excellent wear resistance of diamonds.



Close-up of Cutting Edge



Direct Cutting of Carbide



Chip (Close-up)

### ■ Application Example

Application to Optical Use (Fly-Eye Lens Mold)	Application to Medical Use (μ-TAS Mold)
	1mm 1mm
Work Material : Carbide AF1 (Ultra-fine Grain Carbide)	Work Material: Carbide AF1 (Ultra-fine Grain Carbide)
Finishing Tool: SUMIDIA Binderless	Finishing Tool: SUMIDIA Binderless
R0.5 Ballnose Endmill (Finishing)	R0.3 Ballnose Endmill
(Roughing: R0.5 Diamond-Coated Endmill, 55 minutes)	Finishing Time: 1 hour 28 minutes
Finishing Time : 2 hours 40 minutes	Finishing Conditions : $n = 38,000 \text{min}^{-1}$ $V_f = 95 \text{mm/min}$
Finishing Conditions : $n = 60,000 \text{min}^{-1}$ $v_f = 300 \text{mm/min}$	Machining Allowance=0.003mm
p <sub>f</sub> =0.005mm Oil Mist	$p_{\rm f}$ =0.001mm Wet(Oil based) Cutting Length=8.3m
Surface Roughness : Ra0.015µm	Surface Roughness: Rao.016 to 0.020µm

SUMIDIA Binderless

SUMIDIA SUMIDIA Binderless

> SUMI CRYSTAL